

## FUEL SPILL CLEAN UP

Shelter - Conserve - Sustain

## CONTROLLING SPILLS APPLICATION: Cordon off the area BOOM SOCK NEOPRENE MAT Place over catch basin Place sorbent pads on spill Anchor with brick or Anchor with bries ne. or soil around stone if necessary perimeter Make this distance When joining two or more, as large as possible always overlap min. 15 cm. nchor with brick or stone BOOM SOCK - ACROSS A DITCH Pool on angle to flow Terrest and the second second second Place sorbent pads on pooled spill



## FUEL SPILL CLEAN UP

Shelter - Conserve - Sustain

## **CONTROLLING SPILLS**

